

**#800-0104 LB7 INJECTOR HOLD DOWN BOLT INSTALL**  
**INSTRUCTIONS**

**FITMENT: 2001-2004 DURAMAX 6.6L**

- 1) Verify application, verify part number ordered and instructions match.
- 2) Clean and inspect the new hardware.
- 3) Clean and inspect threads in cylinder head. Thread chase if needed. (M10x1.5)
- 4) Install the Injector Hold Down Bracket and Platform
- 5) Lubricate the underhead of the bolt and threads
- 6) Install by hand until the flange begins to center in hold down
- 7) Torque bolt to:



**THANKS FOR YOUR PURCHASE!**