

# IMPORTANT!

Proper performance of the DHD LML blow shield system requires the installation of the provided washer as pictured below. Installing this washer will help limit front differential movement under load and correct any distortion already evident at the mount.



## **Instructions:**

1. Locate the differential carrier mount on the drivers side frame rail, just above the torsion bar and below the engine oil filter.
2. Remove the bolt and save for reinstallation. This is a pass-through bolt and will require the nut to be held. We recommend you replace this bolt if it shows any signs of damage or degradation. In extreme cases this bolt may be bent.  
Ref. GM Bolt # 11571255 (M12x1.75x98)
3. Add the supplied washer as pictured and reinstall the bolt. Use the bolt to draw the connection tight until all the distortion in the original washer is corrected. Loosen the bolt and tighten to 74lb ft.