



Part # 100-180

LMM Transfer Case
Support Brace



Step 1: Use impact or ratchet wrench to remove bolts shown in the figure to the right.

Step 2: Place DHD Transfer Case Brace in place. Once in place, use the existing hardware to fasten the brace in place. Please follow the torque specifications below.

Tool List:

- Torque Wrench (3/8" Drive)
- 15 mm 3/8" Drive Socket
- T40 Torx Bit
- Extensions (3/8" Drive)

Torque Specifications:

- Transmission Bolts – 37 ft. lbs.
- Transfer Case Bolts – 18 ft. lbs.

